Precautions before use

Before using this product, please read this guide carefully and keep it for future reference. Parents and guardians should read this guide carefully and ensure that children Observe safety precautions.

About security

This product is designed with full emphasis on safety performance, but users still need to abide by the basic rules of use. To ensure safety, please follow the

following rules:

*Only operate away from water and wet environment.

*Only 100-240V voltage can be connected, and it is necessary to ensure that the power supply is well grounded.

*Please ensure that the device is powered off when disassembling the device.

*It is forbidden to operate the device at high temperature (⩾60°C), and do not touch the surface of the case when it is high temperature.

*Be sure to turn off the device when not in use or when leaving the device.

*It is forbidden to knock, collide or disassemble the device without authorization.

*The use of unofficial power adapters, antennas and other accessories is prohibited.

*It is forbidden to plug and unplug all interfaces (power supply, USB, antenna, etc.) on the device while the power is on.

Disclaimer and Warning

*This product is not a toy, please use it under the accompaniment of an adult if you are under the age of 18. Be especially careful when operating in scenes where children are present.

*Be sure to read this document and the User Manual carefully before using the product to understand your legal rights, responsibilities and safety instructions; otherwise, property losses, safety accidents and personal safety hazards may occur. Once you use this product, you are deemed to have understood, approved and accepted all the terms and contents of this document. Users promise to be responsible for their actions and all consequences arising therefrom. The user promises to use this product only for legitimate purposes, and agrees to all the terms and content of this document and any relevant policies or guidelines that CAMMUS may formulate.

*CAMMUS is not responsible for all losses caused by users not using the product in accordance with this "User Guide", and CAMMUS has the right to refuse warranty for equipment damage caused by this.

*CAMMUS reserves the final right to this document in compliance with laws and regulations. CAMMUS has the right to update, revise or terminate this clause without prior notice.

Precautions



In order to use the CP5 Pedal safely and properly, please read this instruction manual carefully before installation and use. It contains important product and safety information; please keep this manual for future reference.


Electricity safety

Do not place the device in a humid or rainy environment to avoid short-circuiting, damage, fire, electric shock and other risks.

Packing list

Brake pedal	*1
Accelerator pedal	*1
Bottom plate	*1
Pedal palm	*2
Non-slip mat	*2
Type-C cable	*1
Hardware package	*1
Warranty card + manual	*1

Dimension overview




Basic Data	
Length, width and height	270*300*140mm
Bare weight	2.4Kg
Sensor form	Hall
Pedal material	cold rolled steel

Support PC mainstream racing games
Requirements (PC): Windows 10, 150 MB free hard disk space, USB 2.0 port

Pedal socket details:

For interface details, refer to the drawing description, as shown in the figure.




Type-C interface: Its identified and used by directly connecting to the host device.

CAN interface: Its identified and used by connecting to a CAMMUS wheelbase.

Working indicator light: Its in working state when its actively on.

Pedal Assembly Instructions:

Please refer to the drawing description for details of the packaging position, as shown in the figure.



When the CP5 pedal is used for the first time, it needs to be connected to the PC software to reset the initial value. After the assembly is completed, connect to the device, then start the CAMMUS application, enter the device and set the pedal extreme value by pressing the pedals all the way to thier furthest position.

installation steps:




Figure 1: Take out the brake pedal and accelerator pedal, and check the mounting holes.




Figure 2: Place the pedal on the base plate, align the protruding shaft with the opening of the base plate box and push it into the opening. Use M4*10 countersunk head bolts to lock from the bottom up, align the holes in the order of A-a, B-b, C-c, D-d to lock.

3




Figure 3: The pedals can be placed where the user is most comfortable with, then take 4 M3*6 countersunk head bolts to align and attatch them in place.

4




Figure 4: Take out the non-slip sticker, tear off the film and paste it on the suspended position where the pedal and the bottom plate do not overlap.

5




Figure 5: Paste anti-slip pads on the bottom plate of the reversible pedal, and paste one piece each on the accelerator pedal and brake pedal to complete the assembly.

APP acquisition and usage tutorial

Users can obtain the [CAMMUS] control software through the following methods, Desktop software:

- Desktop software:
  (cammusracing.com) download the latest and install it.
- Mobile software:

Apple mobile download

Download on the App Store

Download on the App Store

Contact customer service at the designated CAMMUS sales outlets and channels to obtain the download file.

Firmware update

To ensure the best user experience, please update your desktop and firmware to the latest version.

Users can update by:

- Enter CAMMUS official website (cammusracing.com) to download and install the latest desktop.
- Users can update the device firmware through the latest desktop firmware upgrade function.
- If you have any questions, please consult us by email: media@cammus.com

Warranty

The warranty period of this product is 1 year(except EURO,which is 2 years). With the product warranty card, valid invoice or/and other valid certificates for purchasing the product, users can enjoy the product within the valid period. In order for you to enjoy the warranty support of CAMMUS, please do not artificially damage the machine, and do not operate the machine or system abnormally under the guidance of the official or official authorized personnel.

Service Regulations

- The warranty card will not be reissued if it is lost, please keep it properly and present it when repair service is required.
- The warranty card does not assume other responsibilities, including but not limited to any accidental or consequential damage or loss of expected benefits or profits, work stoppage or damage due to use or inability to use the product, etc. responsibility.
- The parts replaced in the maintenance service will not be returned to the user.
- The calculation method of the validity period of the maintenance service is based on the date of purchase.
- If there is any discrepancy between the content recorded in the warranty card and the relevant national laws and regulations, the relevant national laws and regulations shall prevail.

Cases where warranty service is not performed

- Unable to produce valid invoices or/and other valid certificates and warranty cards stipulated in the warranty. (except for those that can prove that the product is within the validity period of the warranty according to the Three Guarantees regulations)
- The warranty card has traces of alteration or the recorded product information is inconsistent with the actual product.
- The barcode on the product is damaged or has traces of alteration.
- Natural consumption, wear and aging of consumable materials.
- Faults caused by lightning strikes or other electrical system reasons.

  Failures caused by force such as accidents, disasters, and wars.
- Damaged due to user behavior (self-refitting, repairing, or dismantling,

refitting, repairing, etc. by a third party not authorized by CAMMUS).

- Software failure of peripherals or accessories that are not configured by the product itself and cause product failure.
- The use of third-party software that is not pre-installed on the product fails and causes product failure.
- It is used for failure or damage of products whose product instructions do not clearly state that they are compatible with the product.
- Faults caused by improper use or storage such as liquid damage, dampness, external force extrusion, drop, etc.
- Using pirated software or infecting with viruses during use causes malfunctions.
- Beyond the validity period of the warranty.
- Failure to use, maintain, and store according to the product instructions.

Products not distributed by CAMMUS.

Supplementary Note

*People who use or experience your device for the first time must be guided by the owner of the device.

*Hair, Loose clothing, cables, skirts, or other objects easily damaged or wrapped around wheel,should be kept away from the simulator.

*For users who use this product for simulated game activities, it is recommended to drive the car 30 minutes after the game is over.

*This instruction manual is only used as a general manual for a single product.

*The products demonstrated in this manual are only used as product descriptions and not as sales instructions.

The specific styles of products are subject to the purchase of the user.

*This manual is subject to update without prior notice. You can check the latest version of "User Manual" and other information on the CAMMUS official website and official information release platform.

www.cammusracing.com If you have any questions or suggestions about this instruction manual and all CAMMUS products, please contact us through information channels.

Thank you again for supporting CAMMUS!


CAMMUS
合格证
CERTIFICATE
产品型号：
Product number
检 验 员：
Inspector:
生产日期：
Production Date:

保修卡
Warranty card

为了您的保修权益，请务必如实填写以下信息
For the sake of your warranty rights, please be sure to fill out the information truthfully

购买日期 Date of purchase		顾客姓名 Customer name		联系方式 contact information	
产品型号 Product number					
地　址 Address					
备　注: Remark:					

保修记录
Warranty record

送修日期 Repair date	故障及处理方法 Faults and solutions	取货日期 pick up date	顾客签名 customer signature


CAMMUS